

critical excitation energy (in *in situ* microanalysis), E_q

Minimum energy to excite a specific analytical signal. The term is most frequently used in connection with the generation of X-ray spectra, designating the *ionization* (binding) *energy* of the orbital on which the transition ends.

1983, 55, 2027