

stand-by state (in analysis)

The condition of an instrument where the analytical procedure can begin immediately.

See *shut-down state*, *start-up time*.

1989, 61, 1664