

vaporization temperature (in electrothermal atomization), T_{vap}

The temperature of the atomization surface at which analyte loss becomes statistically significant.

1992, 64, 257