

interstitial fraction (in chromatography)

The *interstitial volume* per unit volume of a packed column. Defined by:

$$\epsilon_I = V_I/X$$

where V_I is the interstitial volume and X the *column volume*.

O.B. 100